



## SPORTSMAN SNOWMOBILE RACK - CHAINSAW HOLDER INSTALLATION

CONTENTS IN BOX: **CHAINSAW HOLDER, MOTOR SUPPORT, MOTOR REST**

### MOTOR SUPPORT/REST AND HARDWARE PACKAGE (S)

- (2) 1/4" X 1 1/4" LONG ALLEN BOLTS
- (2) 1/4" THIN LOCK NUTS
- (2) 3/8" LONG BLACK SPACERS

### MOUNTING HARDWARE PACKAGE (CM)

- (3) 1/4" X 1" LONG ALLEN BOLTS
- (3) 1/4" LOCK NUTS
- (6) 1/4" WASHERS
- (3) 1/4" LONG WHITE SPACERS
- (1) 1/4" X 1/4" LONG ALLEN BOLT  
(ONLY USED IF MOUNTING SSR AXE HOLDER TO CHAINSAW HOLDER)

**1** Install motor support and rest using package (S)

Insert 1 1/4" allen bolt through chainsaw holder and into 3/8" long spacer, motor support and motor rest as shown in Fig A and B rotate assembly and repeat for second bolt hole. Tighten the 4 nuts shown in Fig. B.



FIG A



FIG B

**2** The Chainsaw holder will be mounted on right side of the rack (throttle side) If you have the SSR Axe holder currently installed it will have to be removed and installed on the chainsaw holder after installation (step 5).



**3** The chainsaw holder will be mounted using packaged (CM) place washers on three 1" bolts and insert through mounting holes of holder then place white 1/4" spacers between rack and holder with washer and lock nut on inside of rack in locations described in (step 4).



TRAIL BREAKER OUTDOORS

1 (705) 698-4266 / [INFO@TRAILBREAKEROUTDOORS.COM](mailto:INFO@TRAILBREAKEROUTDOORS.COM) / [WWW.TRAILBREAKEROUTDOORS.COM](http://WWW.TRAILBREAKEROUTDOORS.COM)



## SPORTSMAN SNOWMOBILE RACK - CHAINSAW HOLDER INSTALLATION

4 The chainsaw holder will be mounted as shown, using one of the two bottom holes circled and the top slots in the rack. On the SSR 130 the bolt on the crossbar (shown with arrow) will be removed and used as the rear mounting location for holder a nut and washer are not needed as the mounting bolt will be threaded back into the crossbar. Once installed tighten all bolts.



5 If you have optional SSR Axe Holder it can be mounted to the Chainsaw holder using the marked holes. (refer to axe holder installation) The hardware from the axe holder will be used for this. Except for the hole marked with the arrow this bolt will require the 1/4" x 1/4" long allen head bolt provided in package (CM).



6 Place chainsaw in holder with bar guard installed.(Bar guard not supplied.) Check the motor support and ensure that the saw is properly supported. Should the support need adjustment, slightly bend it until the saw is level on the motor support. Once proper support is obtained, secure your saw using a using rubber bungee strap (Not supplied).



**!WARNING!** Always securely strap chainsaw in holder. Follow snowmobile manufacturer's weight limit for cargo. Check load on rack periodically.

